

Falcon

Scale Models



Ducati Superleggera V4 (Tamiya 14140) - chain ***Catalog no.: FSM 6***

Installation guide

1. Chain from the FSM6 kit replaces parts D1 and D8 from the base kit. Chain must be split in order to install it on the swingarm. Mark splitting line on the basis of the original chain (from the base kit). Make two cuts (one for each link; do not cut whole chain at once) with very sharp cutters (like Tamiya 74035 Sharp Pointed Side Cutters).

If the fitment between the rear sprocket and the swingarm C18 is too tight use sandpaper to correct the hole size. Be careful not to break fragile resin parts they must fit smoothly.

2. Exhaust meshes from FSM6 kit are used to replace E1 parts from the base kit.

Ducati Superleggera V4 (Tamiya 14140) – dry clutch ***Catalog no.: FSM 7***

Installation guide

1. Parts from the FSM7 kit are used to replicate dry clutch and are substituting F6 part from the base kit. The picture below can be used as reference for painting.



Paint clutch and clutch basket separately. When paint is dry put the clutch basket over the clutch so both parts will look like this



Install created set in D36, in the center of a cylindrical section which is covered by the F6 if base kit is created.

Paint clutch cover and if desired put carbon fiber decals (not part of FSM 7). Install clutch cover on the edge of D36 where original F6 should be glued. One can position the clutch cover as in the picture above.

REMEMBER

Resin parts are fragile and should be used for display purposes not to play with your scale model.